



Field Installation of Cryomodule Vacuum Systems at Fermilab

Curt Baffes (Fermilab)

This document was prepared by the PIP II Collaboration using the resources of the Fermi National Accelerator Laboratory (Fermilab), a U.S. Department of Energy, Office of Science, Office of High Energy Physics HEP User Facility. Fermilab is managed by Fermi Research Alliance, LLC (FRA), acting under Contract No. DE-AC02-07CH11359.

Cryomodules Built, Tested, and/or Operated at Fermilab

- 1.3GHz cryomodules
 - “ILC style” cryomodules incorporated in FAST/IOTA accelerator
 - Fermi-design cryomodules built for LCLS-II project at SLAC
- Fermilab-Style Cryomodules
 - 325MHz Single Spoke Resonator Cavity Cryomodules for Fermilab’s PIP-II Linac
 - 650MHz Elliptical Cavity Cryomodules for PIP-II
- Others
 - ATLAS-style 162.5MHz Half Wave Resonator provided by ANL
 - 1.3GHz single-cell cryomodules in collaboration with DESY


See Tug Arkan’s Talk

PIP-II HB650
Cryomodule



Field Installation Scope

- Installation in Cryomodule Qualification Test Stands
 - CMTS1 Test stand for LCLS-II 1.3GHz Cryomodes
 - PIP-II Integrated Test Stand for PIP-II 325 and 650MHz Cryomodes
- Installation in Accelerators
 - FAST/IOTA
 - PIP-II Injection Test Accelerator
 - PIP-II Linac (installations in 2025+)



- Fermilab's Accelerator R&D Facility
 - SRF accelerator chain supporting Integrable Optics Test Accelerator (IOTA) ring
 - 300MeV e- Linac
 - Two single-cavity 1.3GHz Cryomodules
 - One eight-cavity 1.3GHz ILC-style Cryomodule
- Conservative Vacuum Strategy
 - Cryomodules are stand-alone
 - Brute force ion pumping for beamline
 - Long low-particulate section lengths
 - Ion pumped coupler vacuum
 - Redundant turbopump stations for cryostat
 - Extensive diagnostics



ILC-Style Cryomodule

Cryomodule Test Stand 1 (CMTS1)

- Fermilab is building and testing cryomodules for LCLS-II at SLAC
 - At CMTS1, they are cooled down and powered
 - Cryomodules installed/tested on 1 month cycle
- Vacuum design informed by lessons-learned from FAST/IOTA
- Some simplifications relative to FAST/IOTA
 - Beamline vacuum connection at 1 side only
 - Simplified cryostat vacuum logic
 - Very clean interfaces to enable quick turnaround


See Brian
Hartsell's Talk



CMTS1


PIP-II Linac

- PIP-II is an essential upgrade to Fermilab accelerator complex to enable the world's most intense beam of neutrinos to LBNF/DUNE, and a broad physics research program for decades to come
- Construction underway, completion in 2029
- PIP-II Capabilities
 - 800MeV/1GeV H- Linac
 - 25 Cryomodules of 5 styles
 - All cryomodules are stand-alone (rather than strings)



See Raul
Campos'sTalk

PIP-II Linac Cryomodules




First cryomodules tested with beam,
demonstrated PIP-II beam parameters

Prototype cryomodule –
first phase of cold RF testing
completed

PIP-II Injection Test Accelerator

See Alex
Chen's Talk

- A full-up build of the upstream portion of PIP-II from the Warm Front End through the second cryomodule
- Allowed investigation of vacuum architecture for PIP-II
 - HWR Cryomodule unique vacuum systems
 - Beamline interlock and fast-closing valve implementation
 - More aggressive low-particulate lengths
 - Combination NEG/Ion Pumps (though not yet near the cryomodules in this system)




HWR 162.5 MHz Cryomodule

SSR1 325MHz Cryomodule

PIP-II Integrated Test Stand

- The same physical space was repurposed as a cryomodule test stand
- Testing for prototype and production PIP-II Cryomodules
 - One test stand for 325MHz cryomodules, One test stand for 650MHz cryomodules
 - Testing ongoing now, continues until 2029
- Test stands have independent vacuum systems




HB650 650MHz Cryomodule

SSR1 325MHz Cryomodule

Cryostat Vacuum Field Installation

- Conventional High Vacuum Systems ($\sim 1\text{E-}5$ mbar while warm)
 - Dry screw rougher for new “wet” installations
 - Turbopump stations for each cryomodule to achieve ultimate warm vacuum
 - Typically left on during cryomodule operation
 - PIP-II Integrated Test Stand – station interface is field connection
 - CMTS1 – station interface is permanent and cryostat bellows is field connection



Permanently installed rougher at
CMTS1



Portable turbo station for
650MHz cryomodule test stand


Cryostat Vacuum Field Installation

Talk To:
Ron Kellett

- Leak detection
 - Standard He Mass Spectrometer leak detection
 - High background / O-ring permeation
- Troubleshooting via conventional bag of tricks
- Cryo-to-vacuum leak check via pressurized cryogenic circuits
 - Rough localization via time of flight techniques



N2 bagged flange



Direct cryostat connection example

Cryostat Vacuum Field Installation: Clean Volumes

Talk To:
Dan Lambert

- Temporary clean volumes of various sizes are set up to connect at cryomodule beamline gate valves
- Training and experience critical to setup of volume, QC particle counter, and performance of work

Roll-around softwall
cleanroom →



Particle-safe vacuum pumping cart

Cryostat Vacuum Field Installation: Clean Volumes

We have used

- Permanent overhead filter units
- Roll-around soft-wall cleanrooms
- Glovebox setups

More ergonomic



More flexible



Overhead filter carriage at FAST/IOTA




Overhead filter carriage at CMTS1


Glovebox Approaches: PIP-II HWR-SSR1 Connection



Connection Mockup



Filter setup




Installation

Glovebox approaches: PIP-II Integrated Test Stand

Talk To:
Elias Lopez



HB650 Connection to Test Beamline
Vacuum Station




SSR1 Connection to Test Stand
Beamline Vacuum Station

Clean Volumes for PIP-II





- For the PIP-II Linac, a mix of these approaches will be necessary
- We are studying RAON's T-shaped Clean Booth Concept

J. Kwon, Institute for Rare Isotope Science, TTC 2023

Clean booth



- 3rd (current) version of clean booth
 - HEPA FILTER
 - 2 * 1172-1172-200H
 - 1 * 350-1000-200H (3 fans)
 - Length 2900 mm (expandable 3430 mm)
 - The width of entrance 3000 from injector section
 - Width : 3000 mm
 - **Antistatic PVC** sheet around the booth
- ☺ Easy to move around & out of tunnel
- ☺ No support bar (CM side) required
: Fits all (QWR, HWR-A, HWR-B)




Hook-and-loop fastener
Touch fastener

중이온가속기국책사업 | 7

Beamline Vacuum Field Work

We try to minimize scope of field work




Cryomodule Connection In Test Stands

Talk To:
Brian Hartsell

- We avoid the field connection if possible

CMTS1 Beamline Vacuum



To Beamline
Pumping
Station

To
Cryomodule


Field
Connection
Spool

Cryomodule Connection In Test Stands

Talk To:
Brian Hartsell

- Pumping a cryomodule from one end has been sufficient

CMTS1 Beamline Vacuum



Cryomodule Connection In Test Stands

Talk To:
Genfa Wu


- Use of small NEG/IP pumps in low-particulate service has opened the door to reasonably-sized room-temperature pumping manifolds

PIP-II HB650 Cryomodule

Pump/Gauge manifold installed in cavity string assembly cleanroom

Rides along for


- Assembly
- Transport to test
- RF test
- Transport to PIP-II
- Installation of cryomodule



Adjacent Warm Beamlines

Talk To:
Alex Chen

- Low-particulate handling of adjacent warm beamlines has been trending less conservative
 - Many 10s of meters in FAST/IOTA
 - Just a few meters in PIP-II Injection Test Accelerator
- See Alex Chen's talk




PIP-II Injector Test Accelerator

Particle Safe Vacuum Cart

Talk To:
Lucy Nobrega

- Mass Flow Control for slow pumping/backfilling in high pressure regime where particulate transport is more likely
- Standard design deployed across Fermilab
- Cart design includes
 - Mass flow controllers
 - Scroll, Turbo and Ion pumping
 - Gauges and Diagnostics



A skilled workforce is the key to success

- Skilled and dedicated technicians are essential to this work
- Developing and continuously improving these skills is a “must”
- Thanks to the OLAV organizers for this opportunity to cross-pollinate



Pay no attention to the man
behind the curtain!



Do pay attention to the man or
woman behind the curtain!

Thank you for your attention!

This work has been authored by Fermi Research Alliance, LLC under Contract No. DE-AC02-07CH11359 with the U.S. Department of Energy, Office of Science, Office of High Energy Physics

